

Garment Information



Men's Eddie Bauer **Packable Wind Jacket**

Wind was the inspiration for this compact layer. It packs down into its own logo'd pocket, making it easy to carry wherever you go.

Fabric

• 100% nylon

Features

- · Hood with locking draw cords for adjustability
- Contrast reverse coil zipper
- Underarm vents
- Packable zippered chest pocket
- Front unzippered pockets
- Elastic cuffs and an open hem
- Contrast Eddie Bauer logo on right chest


Care Instructions

Secure all garment before laundering. Machine wash warm delicate separately. Use mild detergent. Rinse thoroughly. Do not bleach. Tumble dry low or for best result. Line dry. Do not iron. Do not dry clean.

SIZE CHART

		XS	S	М	L	XL	2XL	3XL	4XL
С	hest	32-34	35-37	38-40	41-43	44-46	48-50	52-54	55-57

HOW TO MEASURE



Measure under the arm and around the fullest part of the ches with arms down, keeping tape horizontal.



